Wiring Diagram - EZGO RXV (After Jan 23, 2012)

Using TAC2 Module PN: 40-000620





35 POS
TE 1-776231-1



P1: Key In / Logic Power In	P1: RED
P2: Reverse Buzzer	P2: BLK
P3: na	P3: na
P4: Brake Light Relay Release	P4: PUR
P5: Brake Solenoid Out	P5: BLK
P6: Main Solenoid Out	P6: BLK
P7: Logic Power GND	P7: BLK
P8: Motor Temperature In	P8: PNK
P9: Foot Switch In	P9: L.BLU
P10:Tow Switch In	P10:BLK
P11:Charger Interlock In	P11:L.BLU
P12:Brake Switch In	P12:WHT
P13: na	P13: na
P14: na	P14: na
P15:+5V PF	P15:ORG
P16:Throttle In	P16:YEL
P17:Brake In	P17:L.GRN
P18:Anolog GND	P18:BLK
P19:na	P19:na
P20:na	P20:RED
P21:na	P21:na
P22:Forward In	P22:GRN
P23:CAN Positive	P23:RED/WHT
P24:NA	P24:na
P25:+12V Output	P25:PUR
P26:+5V PF	P26:ORG
P27:na	P27:na
P28:na	P28:YEL
P29:na	P29:ORG
P30:SOC Display Out	P30:GRY
P31:SPD A In	P31:BLU/WHT
P32:SPD B In	P32:WHT
P33:Reverse In	P33:WHT
P34:Analog Ground	P34:GRN/WHT
P35:CAN Negative	P35:ORG/RED

Mating 35 POS
TE 776164-1

On The Fly Programmer

8 POS Molex
39-01-3089 Housing
39-00-0040 Pin



P1: +12V POLY
P2: OTF REGEN
P3: OTF SPEED
P4: OTF ACCELERATION
P5: +5V EXT
P6: OTF LOOCK
P7: REVERSE BUZZER
P8: GND POLY

Revision History

20201208 Original